








Pushbutton Switch&Indicator



Description	Type
Installed light circular LED 24V/AC/DC Neon 220V/AC	AD16-AXD
 	
	



Description	Type
Pushbutton single knife LED 24V/AC/DC Neon 220V/AC	AD16-11CFD AD16-11CFDL
 	
	



Description	Type
Installed light square LED 24V/AC/DC Neon 220V/AC	AD16-FXD
 	
	


Description	Type
Installed light circular double knife LED 24V/AC/DC Neon 220V/AC	AD16-22AD AD16-ADL
 	
	




Description	Type
Installed light rectangular LED 24V/AC/DC Neon 220V/AC	AD16-CFXD
 	
	

Description	Type
Installed light square double knife LED 24V/AC/DC Neon 220V/AC	AD16-22FXD AD16-22FDL
 	
	

Description	Type
Pushbutton single knife LED 24V/AC/DC Neon 220V/AC	AD16-11AD AD16-11ADL
 	
	

Description	Type
Installed light rectangular double knife LED 24V/AC/DC Neon 220V/AC	AD16-22CFD AD16-22CFDL
 	
	

Description	Type
Pushbutton single knife LED 24V/AC/DC Neon 220V/AC	AD16-11FD AD16-11FDL
 	
	

Description	Type
Installed light circular single knife LED 24V/AC/DC Neon 220V/AC with protection cover IP40	AD16-11ADFG AD16-11ADFL
 	
	

Pushbutton Switch & Indicator

Description	Type
 Installed light square single knife LED 24V/AC/DC Neon 220V/AC with protection cover IP40 NO+NC X1 NO NC X2 AD16-11FDFG	AD16-11FDFG AD16-11FDFGL NO+NC X1 NO NC X2 AD16-11FDFG

Description	Type
 Mushroom button single knife circular NO+NC NO NC C AD16-M	AD16-11M AD16-11ML AD16-22M AD16-22ML 2NO+2NC NO NC NO NC C C AD16-M

Description	Type
 Installed light square single knife LED 24V/AC/DC Neon 220V/AC with grade IP40 NO+NC X1 NO NC X2 AD16-11CFDFG	AD16-11FDFG AD16-11FDFGL NO+NC X1 NO NC X2 AD16-11CFDFG

Description	Type
 Emergency push button push locking in clockwise direction, move reset single knife NO+NC NO NC C AD16-11ZS	AD16-11ZS NO+NC NO NC C AD16-11ZS

Description	Type
 Indicator Buzzer NO+NC X1 NO NC X2 AD16-MF	AD16-MF NO+NC X1 NO NC X2 AD16-MF

Description	Type
 Emergency push button push locking in clockwise direction, move reset single knife 2NO+2NC NO NC NO NC C C AD16-22ZS	AD16-22ZS 2NO+2NC NO NC NO NC C C AD16-22ZS

Description	Type
 Installed light Mushroom button single knife LED 24V/AC/DC Neon 220V/AC NO+NC X1 NO NC X2 AD16-11MD	AD16-11MD AD16-11MDL NO+NC X1 NO NC X2 AD16-11MD

Description	Type
 90° 2 Position NO+NC NO NC C AD16-11XA	AD16-11XA-2P AD16-11XA-3P NO+NC NO NC C AD16-11XA

Description	Type
 Installed light Mushroom button single knife LED 24V/AC/DC Neon 220V/AC double knife 2NO+2NC NO NC X1 NO NC X2 AD16-22MD	AD16-22MD AD16-22MDL 2NO+2NC NO NC X1 NO NC X2 AD16-22MD

Description	Type
 90° 2 Position NO+NC NO NC C AD16-11XF	AD16-11XA-2P AD16-11XA-3P NO+NC NO NC C AD16-11XF

Pushbutton Switch

Description	Type
90° 2 Position	AD16-11YA-2P AD16-11YA-3P
	NO+NC NO NC C
○ Null	
AD16-11YA	


Description	Type
90° 2 Position	AD16-11YF-2P AD16-11YF-3P
	NO+NC NO NC C
○ Null	
AD16-11YF	


Description	Type
90° 2 Position	AD16-11YCF-2P AD16-11YCF-3P
	NO+NC NO NO NC C
○ Null	
AD16-11CF	


Description	Type
45° 3 Position	AD16-22YA-2P AD16-22YA-3P
	2NO+2NC NO NC NO NC C C
○ Null	
AD16-22YA	


Description	Type
45° 3 Position	AD16-22YF-2P AD16-22YF-3P
	2NO+2NC NO NC NO NC C C
○ Null	
AD16-22YF	

Description	Type
45° 3 Position	AD16-22YCF-2P AD16-22YCF-3P
	2NO+2NC NO NC NO NC C C
○ Null	
AD16-22YCF	

Description	Type
90° 2 Position	AD16-11XCF-2P AD16-11XCF-3P
	NO+NC NO NC C
●	
AD16-11XCF	

Description	Type
45° 3 Position	AD16-22XA-2P AD16-22XA-3P
	2NO+2NC NO NC NO NC C C
●	
AD16-22XA	

Description	Type
45° 3 Position	AD16-22XF-2P AD16-22XF-3P
	2NO+2NC NO NC NO NC C C
●	
AD16-22XF	

Description	Type
45° 3 Position	AD16-22XCF-2P AD16-22XCF-3P
	2NO+2NC NO NC NO NC C C
●	
AD16-22XCF	